

## Appendix A: Pressurized Distribution Design Worksheet

Please enter the results of your calculations for each step.

### Absorption Area Design

Absorption Area Design Notes:	Step:
<p>For residential systems, determine the number of bedrooms for design. For <b>non-residential systems</b>, determine the number of gallons per day using guidance from R317-4.</p> <p>For <b>absorption systems</b> and <b>mound systems</b>, use 150 gallons per day per bedroom.</p> <p>For <b>packed bed systems</b>, use:</p> <p style="padding-left: 40px;">A minimum of 300 gallons per day for two bedrooms 100 gallons per day for each additional bedroom.</p>	<p><b>1. Daily flow rate</b></p> <p><b>Number of bedrooms:</b></p> <p>_____</p> <p><b>Total gallons per day:</b></p> <p>_____</p>
<p>For <b>pressurized trenches for residential and non-residential systems</b>, select the loading rate using guidance from R317-4</p> <p>For <b>mound systems</b>, use 1.0 gal/sq. ft./day</p> <p>For <b>packed bed systems</b>, select from:</p> <p style="padding-left: 40px;">Intermittent sand filter: Sand media = 1.0 gal./sq. ft./day; Sand fill = 1.2 gal./sq. ft./day</p> <p style="padding-left: 40px;">Recirculating sand filter = 5.0 gal./sq. ft./day</p> <p style="padding-left: 40px;">Recirculating gravel filter: 15.0 gal./sq. ft./day</p> <p style="padding-left: 40px;">Textile filter: 30.0 gal./sq. ft./day</p> <p style="padding-left: 40px;">Peat filter: 5.0 gal./sq. ft./day</p> <p style="padding-left: 40px;">Synthetic polystyrene media filter: 21 gal./sq. ft./day</p> <p style="padding-left: 40px;">Synthetic open cell foam media filter: 20 gal./sq. ft./day and 6 gal./cu. ft./day</p>	<p><b>2. Maximum loading rate</b></p> <p>_____ gal/sq. ft./day</p>

Absorption Area Design Notes:	Step:
<p>For <b>pressurized trenches</b>, use absorption area sizing tables from R317-4</p> <p>For <b>pressurized trenches after packed bed systems</b>, use absorption area sizing tables from R317-4 and allowable reduction factors.</p> <p>For <b>mound systems</b>, use values of A (absorption area width) and B (absorption area length) from Mound Design Worksheet</p> <p>For <b>packed bed systems</b>, use:</p> <p>Daily flow rate (from Step 1)/maximum loading rate (from Step 2) = required treatment absorption area.</p>	<p><b>3. Required absorption treatment area</b></p> <p>_____ sq. ft.</p>
<p>For <b>pressurized trenches</b> and <b>packed bed systems</b>, use:</p> <p style="text-align: center;">Length x width = absorption treatment area</p> <p>The layout will be dependent on the characteristics of the specific site.</p> <p>For <b>mound systems</b>, use the values of A and B from the Mound Design Worksheet (available from the Utah On-Site Wastewater Treatment Training Program).</p>	<p><b>4. Sketch a proposed absorption treatment area for the system being designed, using the required absorption area</b></p>

### Pressure Network Design

Pressure Network Design Notes:	Step:
<p>1/8 inch – Can be used on all <b>alternative systems &amp; pressurized trenches</b></p> <p>5/32 inch – Typically used in <b>pressurized trenches</b></p> <p>3/16 inch – Can be used in <b>mounds</b> or <b>pressurized trenches</b></p> <p>1/4 inch – Can be used in <b>mounds</b> (but generally not recommended for use in pressurized system design).</p>	<p><b>5. Orifice diameter</b></p> <p>_____ inch</p>

Pressure Network Design Notes:	Step:
<p>Select the squirt height using orifice diameter (Step 5)</p> <p>1/8 inch: 3 - 5 ft</p> <p>5/32 inch: 2 - 4 ft</p> <p>3/16 inch: 2 - 3.5 ft</p> <p>1/4 inch: 2 - 2.5 ft</p>	<p><b>6. Minimum squirt height</b></p> <p>_____ ft.</p>
<p>Determine the orifice flow rate (See Appendix B <i>Table B-5: Orifice flow rates</i>) using the orifice diameter (Step 5)</p> <p>Examples of orifice flow rates include:</p> <p>1/8 inch with 5 ft squirt = 0.41 gpm</p> <p>5/32 inch with 3.5 ft squirt = 0.54 gpm</p> <p>3/16 inch with 3.5 ft squirt = 0.78 gpm</p> <p>1/4 inch with 2.5 ft squirt = 1.17 gpm</p>	<p><b>7. Orifice flow rate in gallons per minute (GPM)</b></p> <p>_____</p>
<p>Select the orifice spacing:</p> <p>1 orifice/6 ft<sup>2</sup> – <b>Mounds</b></p> <p>1 orifice/4 ft<sup>2</sup> - <b>Intermittent sand filter</b></p> <p>1 orifice/4 ft<sup>2</sup> or less - <b>Recirculating sand filter, recirculating gravel filter, textile filter</b></p> <p>For <b>pressurized trenches</b>, orifices are typically placed every 2 to 4 feet along each pressurized lateral.</p>	<p><b>8. Orifice spacing</b></p> <p>_____ ft.</p>

Pressure Network Design Notes:	Step:
<p>Based on orifice spacing and shape of distribution area (from Step 4 sketch), determine number and length of laterals:</p> <p><b>Number of laterals</b> is all laterals in the system</p> <p><b>Number of laterals dosed by pump</b> is the number of laterals dosed when the pump runs. It is the same as above when zones are not used. It is the number of laterals within the zone when zones are used. This number is used for determining the design flow rate of the pump in Step 14.</p> <p><b>For end feed:</b> lateral length =  Absorption length minus 0.5 to 1 foot</p> <p><b>For center feed:</b> lateral length =  Absorption length divided by 2 minus 0.5 to 1 foot</p> <p>Laterals should extend to within 6 inches to 1 foot of the end of the absorption area.</p> <p>The distance from the laterals to the edge of the infiltrative area should be 6 inches to 1 foot for bed areas and 1 foot to 1.5 feet for trenches.</p>	<p><b>9. Number and length of laterals</b></p> <p><b>Number of laterals</b>  _____</p> <p><b>Number of laterals dosed by pump</b>  _____</p> <p><b>Length of laterals</b>  _____ ft.</p> <p><b>Add the laterals to the sketch in Step 4</b></p>
<p>From Step 8 and Step 9:</p> <p>Number of orifices = (lateral length/orifice spacing) + 1</p> <p>If the calculation results in a fraction, disregard the fraction and add one.</p>	<p><b>10. Number of orifices in each lateral</b></p> <p>_____</p>
<p>From Step 7 and Step 10:</p> <p>(Orifice flow rate) x (Number of orifices)</p>	<p><b>11. Lateral flow rate</b></p> <p>_____ GPM</p>

Pressure Network Design Notes:	Step:
<p>Size the lateral diameter to ensure flow within the lateral is within 10%.</p> <p>Use orifice diameter from Step 5.</p> <p>Use Graphs B1 through B8 in Appendix B to determine minimum lateral diameters:</p> <ul style="list-style-type: none"> <li>Use Graph B-1 or B-2 for 1/8 inch orifice</li> <li>Use Graph B-3 or B-4 for 5/32 inch orifice</li> <li>Use Graph B-5 or B-6 for 3/16 inch orifice</li> <li>Use Graph B-7 or B-8 for 1/4 inch orifice</li> </ul>	<p><b>12. Lateral sizing</b></p> <p>_____ in.</p>
<p>Determine lateral head loss using Method 1 or 2:</p> <p><b>Method 1:</b> Use 1/3 of the squirt height from Step 6:</p> <p style="text-align: center;">(squirt height) x (0.33)</p> <p><b>Method 2:</b> Calculate the head loss based on solid pipe 1/3 the length of the perforated lateral from Step 9, using the lateral flow rate from Step 11 and the diameter of the lateral from Step 12. See Appendix B <i>Table B-6, Frictional Head Loss per 100 feet of Solid Pipe.</i></p>	<p><b>13. Lateral head loss</b></p> <p>_____ ft.</p>
<p>Calculate flow rate from all laterals dosed at one time. This will be the total flow rate for all laterals or all laterals within a zone:</p> <p style="text-align: center;">(No. of laterals from Step 9) x (Lateral flow rate from Step 11) = Design Flow Rate.</p>	<p><b>14. Design flow rate</b></p> <p>_____ GPM</p>

Pressure Network Design Notes:	Step:
<p>Determine the size of the manifold using Method 1 or 2:</p> <p><b>Method 1:</b> Use the same size pipe used for the force main in Step 18.</p> <p><b>Method 2:</b> Calculate the head loss within the manifold using various sizes of pipe and using 1/2 of the total design flow from Step 14.</p> <p>Use Appendix B <i>Table B-6: Frictional Head Loss per 100 feet of Solid Pipe</i>.</p> <p>Select an “acceptable” head loss - usually select the smallest possible pipe.</p> <p>Manifold head loss should be &lt;40% of total dynamic head (TDH) from Step 23.</p>	<p><b>15. Manifold sizing</b></p> <p>_____ in.</p>
<p>Determine manifold head loss using Appendix B <i>Table B-6: Frictional Head Loss per 100 feet of Solid Pipe</i></p>	<p><b>16. Manifold head loss</b></p> <p>_____ ft.</p>
<p>Length of pipe from the pump discharge to the beginning of the manifold (site-specific).</p>	<p><b>17. Force main length</b></p> <p>_____ ft.</p>
<p>Use Appendix B <i>Table B-6: Frictional Head Loss per 100 feet of Solid Pipe</i> to determine the pipe diameter.</p> <p>Pick a pipe diameter with an acceptable range of head loss.</p> <p>May be an iterative process.</p>	<p><b>18. Force main diameter</b></p> <p>_____ in.</p>
<p>Determine the force main head loss from Appendix B <i>Table B-6: Frictional Head Loss per 100 feet of Solid Pipe</i> using the force main pipe size diameter from Step 18.</p>	<p><b>19. Head loss in force main</b></p> <p>_____ ft.</p>

Pressure Network Design Notes:	Step:
<p>Estimate additional head loss for fittings, valves, etc. Use Method 1 or 2</p> <p>Method 1: Add 50% of the force main head loss from Step 19 to account for fittings, valves, etc.</p> <p>Method 2: Determine the “equivalent” pipe lengths for fittings, valves, etc. and determine the head loss from Appendix B <i>Table B-7: Frictional losses through plastic fittings</i>.</p>	<p><b>20. Miscellaneous head loss</b></p> <p>_____ ft.</p>
<p>Determine the head loss through automatic distributing valve. This information is usually supplied by the manufacturer.</p>	<p><b>21. Head loss for systems with multiple zones (if used)</b></p> <p>_____ ft.</p>
<p>The vertical distance (elevation difference) from the water level in the pump tank to the water level at the discharge point (site-specific).</p>	<p><b>22. Elevation head difference</b></p> <p>_____ ft.</p>
<p>To determine the Total Dynamic Head (TDH), add together:</p> <p style="padding-left: 40px;">Squirt Height (Step 6) _____</p> <p style="padding-left: 40px;">Lateral Head Loss (Step 13) _____</p> <p style="padding-left: 40px;">Manifold Head Loss (Step 16) _____</p> <p style="padding-left: 40px;">Force Main Head Loss (Step 19) _____</p> <p style="padding-left: 40px;">Miscellaneous Head Loss (Step 20) _____</p> <p style="padding-left: 40px;">Zone Valve Head Loss (Step 21) _____</p> <p style="padding-left: 40px;">Elevation head difference (Step 22) _____</p> <p style="padding-left: 40px;">Result in feet = TDH _____</p>	<p><b>23. Total Dynamic Head (TDH)</b></p> <p>_____ ft.</p>

Pressure Network Design Notes:	Step:
<p style="text-align: center;">Design Flow Rate (Step 14) gpm _____</p> <p style="text-align: center;">Total Dynamic Head (Step 23) ft. _____</p>	<p><b>24. Pump Selection</b></p> <p><b>USE PUMP CURVES TO SELECT THE CORRECT PUMP</b></p>
<p>The dose volume should not exceed 10% of the daily design flow. Smaller dose volumes are preferred.</p> <p>For systems that drain back to the pump tank after each cycle, the volume of the force main should be added to the dose volume.</p> <p>Pipe volumes are calculated using Appendix B <i>Table B-8: Void volume for various diameter pipes.</i></p>	<p><b>25. Dose Volume</b></p> <p><b>System Dose Volume</b></p> <p>_____ gal.</p> <p><b>Pipe Volume</b></p> <p>_____ gal.</p> <p><b>Total Dose Volume</b></p> <p>_____ gal.</p>